


Tx

Rx



optional

3 - PTT

5 - TX Audio

7 - Gnd

8 - COS/SQL (optional)

11 - RX Audio - flat

15 speaker + } connect the
16 speaker - } two if you
want internal
speaker to work



D sub
female
facing you

- 1 - Audio In
- 2 - Radio COS (squench)
- 3 - Audio out
- 4 - PTT
- 5 - GND