



- 20 11
- 16 10
- 5 3
- 0 62
- 0 61
- 0 60
- 0 59
- 0 58
- 0 57
- 0 56
- 0 55
- 0 54
- 0 53
- 0 52
- 0 51
- 0 50
- 0 49
- 0 48
- 0 47
- 0 46
- 0 45
- 0 44
- 0 43
- 0 42
- 0 41
- 0 40
- 0 39
- 0 38
- 0 37
- 0 36
- 0 35
- 0 34
- 0 33
- 0 32
- 0 31
- 0 30
- 0 29
- 0 28
- 0 27
- 0 26
- 0 25
- 0 24
- 0 23
- 0 22
- 0 21
- 0 20
- 0 19
- 0 18
- 0 17
- 0 16
- 0 15
- 0 14
- 0 13
- 0 12
- 0 11
- 0 10
- 0 9
- 0 8
- 0 7
- 0 6
- 0 5
- 0 4
- 0 3
- 0 2
- 0 1
- DIODE
- 25C2236
- 25A1267
- 5V251Y
- TDA2003
- 25C2078
- 25C2314
- DIRECTION TO THE END OF CONDUCTING CONNECTION
- All Resistors in Ohm.
- All Cond. in Microfarad.
- (M) = Mylar (CH) = NPO
- (T) = Tantalum

# SCHEMATIC DIAGRAM HT4000 FM

Parts subject to change without notice.

