



DC POWER CORD

SP- 3 OHMS

ANTENNA CONNECTOR J3

PUBLIC ADDRESS SPEAKER JACK J1

EXTERNAL SPEAKER JACK J2

RF POWER/ "S" METER

MICROPHONE CONNECTOR J4

VOLUME/OFF CONTROL VR2/S1

SQUELCH/PA CONTROL VR3/S2

ANL/OFF SWITCH S3

LED

CHANNEL INDICATOR D803

DIM/BRITE SWITCH S4

XMIT INDICATOR