

# PC - 893 Main PCB

VR10



VR9



L30



VR8



VR7



VR5



VR11



TP7



TP6



TP8

## TX ALIGNMENT POINTS

L42



L41



L43



L44



VR3



VR4

