

PRESIDENT JFK

VCO ALIGNMENT =====

1. Test Equipment Required

- a) Oscilloscope (100 MHz).
- b) DC Power Supply (13.8v, 3 Amps).
- c) DC Voltmeter (DVM).
- d) Frequency Counter (100 MHz).

2. Alignment Procedure

STEP	PRESET TO	ADJUSTMENT	REMARKS
1	Channel :1 Band : MID Mode : RX	L17	Connect DC Voltmeter to TP1 (Lead of R72). Adjust L17 for 1.2 Volts \pm 0.1 Volt on Voltmeter.

3. Test Equipment Connection

